


# INSTALLATION INSTRUCTIONS

## installation

SALIOT is  certified for use on horizontally-mounted Edison Price Lighting three-conductor, 120-volt, 20-amp track.

**Not suitable for use on electrical circuits including dimming controls of any kind.**

**Do not attempt to force fixture into a two-conductor Edison Price Lighting track system.**

**Not suitable for use on vertically-mounted track**

### MOUNTING

- Turn off power to track.
- Align track adapter with track and insert upward until both adapter springs snap into place.

**Note:** If track has been wired for two-circuits, fixture may be changed from one circuit to the other by rotating the entire fixture 180°.

### LOCKING

Lock fixture into track.

- Loosen nut on one adapter spring, rotate cam nut
- Repeat for second spring.

## removal

- Turn off power to track

### UNLOCKING

- Loosen nut on one adapter spring, rotate cam nut into open position.
- Repeat for second spring.

### REMOVAL

- Compress one track adapter spring and pivot the fixture downward. Pull fixture out of track.

